

NEW



WIRELESS CONVENIENCE AT YOUR FINGERTIPS



- *Remotely downloadable when using an ESCORT REDi device.*
- *User-friendly multi-language software for easy programming and download*
- *Customisable alarm settings and programmable start function*
- *Large LCD display with multi function viewing*
- *Internal or external sensor options*



Simple 2 second push button start (or until lines appear on LCD).



Download via the USB to Serial Port Adapter cable, no interface required.



Removable battery cover for easy battery replacement.



Moulded plastic lug allows logger to be hung from a hook or padlocked to an item.

ESCORT Wireless Mini - Specifications

Temperature Range	Internal or External options
Sensors	±0.5°C
Accuracy	0.5°C
Resolution	Operating Temp -20 to +70°C
Liquid Crystal Display	1st Button Press – High, Low & Average Readings 2nd Button Press – Time Spent Under/Over Specification
Communication Frequency	EA-RI-8 – 868.35 MHZ (Europe & South Africa) EA-RI-9 – 916.5 MHZ (America, Oceania & Africa)
Communication Range	Indoor: 16m Outdoor: 70m (performance may vary due to environment conditions)
Measuring Response	T90 of 5 minutes in moving air
Memory	1896 samples
Data Recovery	Download via IBM compatible PC at 2400bps
Sampling Frequency	1 to 255 minutes
Recorder Start-Up	Long Button Press (2 seconds or until lines appear on LCD)
Security	Logger data and settings can be protected through programming the logger with a password using ESCORT Console software
Time and Date	Real Time Clock, accuracy better than 1 minute per month at ambient. Multiple time zones supported
IP Rating	IP51
Size	80 x 57 x 20 mm (excluding lug)
Weight	70 grams
Case Material	Polycarbonate/ABS
Storage Temperature	-40 to +85°C
Power Source	User Replaceable Coin Cell Battery
Typical Battery Life	1 to 2 years
Warranty	24 Months (excluding batteries)



ESCORT Console Software - Specifications

- Available Languages: English, German, French, Spanish, Italian and Polish
- Console Standard version
- Recorded data viewable in graphs or tabular formatted reports
- Support of most models of ESCORT Data Logging Systems' products

Additional features for extended Professional version

- Multi-Graph
- Multi-Link
- Login and Digital signatures when used with ESCORT User Admin Package
- Compliance with CFR Title 21 Part 11 when used with ESCORT User Admin Package



USB to Serial Port Adapter - Specifications

USB Port	USB Specification Version 1.1 and 2.0 compliant
RS232 Plug	Supports RS232 Serial Interface (DB9)
Transfer Rate	Supports over 1Mbps Data Transfer
Warranty by EDLS	12 Months
Cable Length	1.8 Metres

 **ESCORT**

ESCORT DLS Messtechnik AG
Dorfstrasse 14 CH - 8904 Aesch
Tel: (+41) 7777100 Fax: (+41) 7777102